



Front of mailbox should be 0 to 6 inches **behind** back of curb

42" - 48"

Front of paper boxes should be flush with vertical post

"Clear Zone"

10"

# Recommended Mailbox Installation